

User's Guide

PowerPro with ***PowerFlow+*** Firmware **8 Channel Power Quality Analyzer / Data Recorder**



PowerPro User's Guide

Copyright © 2014 CANDURA INSTRUMENTS.

All Rights Reserved.

The information in this document is subject to change without notice.

CANDURA INSTRUMENTS has made every effort to ensure the accuracy of this manual. However, CANDURA INSTRUMENTS makes no warranties with respect to this documentation and disclaims any implied warranties of merchantability and fitness for a particular purpose. CANDURA INSTRUMENTS assumes no responsibility for any errors that may appear in this document.

Trademarks

PowerPro is a registered trademark of Candura Instruments

All other product names are copyright and may be trademarks and/or registered trademarks of their respective companies.

Manufactured by:

CANDURA Instruments
775 Pacific Rd, Unit #26
Oakville, Ontario
Canada

Document number: CID1002.05

Date: April 1, 2014

Printed in Canada

3 Years Limited Warranty

Limited Warranty

This Limited Warranty applies to the Candura Instruments - branded hardware products sold by or leased from Candura Instruments, its worldwide subsidiaries, affiliates, authorized resellers, or country distributors (collectively referred to in this Limited Warranty as "Candura") with this Limited Warranty ("Candura Product").

These terms and conditions constitute the complete and exclusive warranty agreement between you and Candura regarding the Candura Product you have purchased or leased. These terms and conditions supersede any prior agreements or representations, including representations made in Candura sales literature or advice given to you by Candura or an agent or employee of Candura that may have been made in connection with your purchase or lease of the Candura Product. No change to the conditions of this Limited Warranty is valid unless it is made in writing and signed by an authorized representative of Candura.

Warranty disclaimer

EXCEPT AS EXPRESSLY SET FORTH IN THIS LIMITED WARRANTY AND TO THE GREATEST EXTENT ALLOWED BY LAW, CANDURA MAKES NO OTHER REPRESENTATIONS, WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED REPRESENTATIONS, WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, AND NON-INTERFERENCE. CANDURA DOES NOT WARRANT THAT YOUR USE OF THE CANDURA PRODUCT WILL BE UNINTERRUPTED OR ERROR-FREE. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW ARE LIMITED IN DURATION TO THE LIMITED WARRANTY PERIOD, TO THE GREATEST EXTENT ALLOWED BY LAW. SOME STATES OR COUNTRIES DO NOT ALLOW A LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS. IN SUCH STATES OR COUNTRIES, SOME EXCLUSIONS OR LIMITATIONS OF THIS LIMITED WARRANTY MAY NOT APPLY TO YOU.

Warranty period

Customer satisfaction is of the utmost importance to Candura Instruments. Each Candura Product ships with a three-year limited warranty that covers the Analyzer and select accessories.

The analyzer batteries, located internal to the analyzer, is covered by the same warranty period as the analyzer warranty (three-year limited warranty) and are considered functioning batteries when the following conditions exist: the battery powers the analyzer; the battery is able to charge and discharge; the battery does not have visible defects (defects caused by dropping the analyzer or by other impacts, or leaving the product in extreme environments are not covered by the warranty).

The warranty period for this Candura Product is three (3) year from the date of product purchase. The Limited Warranty Period starts on the date of purchase or lease from Candura. Your dated sales or delivery receipt, showing the date of purchase or lease of the product, is your proof of the purchase or lease date. You may be required to provide proof of purchase or lease as a condition of receiving warranty service.

Warranty coverage

Candura warrants that the Candura Product and all the internal components of the product that you have purchased or leased from Candura are free from defects in materials or workmanship under normal use during the Limited Warranty Period. You are entitled to warranty service according to the terms and conditions of this document if a repair to your Candura Product is required within the Limited Warranty Period. This Limited Warranty extends only to the original purchaser or lessee of this Candura Product and is not transferable to anyone who obtains ownership or use of the Candura Product from the original purchaser or lessee.

Repair or replacement

Candura products are manufactured using new materials or new and used materials equivalent to new in performance and reliability. Spare parts may be new or equivalent to new. Spare parts are warranted to be free from defects in material or workmanship for thirty (30) days or for the remainder of the Limited Warranty Period of the Candura Product in which they are installed, whichever is longer.

During the Limited Warranty Period, Candura will repair or replace the defective component parts or the Candura Product. All component parts or hardware products removed under this Limited Warranty become the property of Candura. The replacement part or product takes on either the Limited Warranty status of the removed part or product or the thirty (30) day limited warranty of the spare part. In the unlikely event that your Candura Product has a recurring failure, Candura, at its discretion, may elect to provide you with a replacement unit of Candura's choosing that is at least equivalent to your Candura Product in hardware performance. Candura reserves the right to elect, at its sole discretion, to give you a refund of your purchase price or lease payments (less interest) instead of a replacement. THIS IS YOUR EXCLUSIVE REMEDY FOR DEFECTIVE PRODUCTS. HOWEVER YOU MAY ALSO HAVE OTHER RIGHTS THAT MAY VARY FROM STATE TO STATE OR FROM COUNTRY TO COUNTRY.

Software and data

YOU SHOULD MAKE PERIODIC BACKUP COPIES OF THE DATA STORED ON YOUR MEMORY CARDS OR HARD DRIVE AS A PRECAUTION AGAINST POSSIBLE FAILURES, ALTERATION, OR LOSS OF THE DATA. BEFORE RETURNING ANY UNIT FOR SERVICE, BE SURE TO BACK UP DATA AND REMOVE ANY CONFIDENTIAL, PROPRIETARY, OR PERSONAL INFORMATION. CANDURA IS NOT RESPONSIBLE FOR DAMAGE TO, LOSS OF, OR DISCLOSURE OF ANY PROGRAMS, DATA, OR REMOVABLE STORAGE MEDIA. CANDURA IS NOT RESPONSIBLE FOR THE RESTORATION OR REINSTALLATION OF ANY PROGRAMS OR DATA OTHER THAN SOFTWARE INSTALLED BY CANDURA WHEN THE PRODUCT IS MANUFACTURED.

CANDURA DOES NOT WARRANT SOFTWARE PRODUCTS, INCLUDING ANY SOFTWARE PRODUCTS, OPERATING SYSTEM OR FIRMWARE PREINSTALLED BY CANDURA. Candura's only obligations with respect to software and firmware distributed by Candura under the Candura brand name are set forth in the applicable end-user licensor or program license agreement. Non-Candura hardware and software products are provided "AS IS". However, non-Candura manufacturers, suppliers, or publishers may provide their own warranties directly to you.

Warranty exclusions

This Limited Warranty does not extend to:

- Expendable parts;
- Any product from which the serial number has been removed or altered;
- Cosmetic damage or ordinary wear and tear;
- Damage or non-functionality that results from (i) failure to follow the instructions that came with the product; (ii) accident, misuse, abuse, or other external causes; (iii) operation outside the usage parameters stated in the then current user documentation for the product; or (iv) use of parts not manufactured or sold by Candura; or
- Damage or non-functionality due to modifications of service by anyone other than (i) Candura, (ii) a Candura authorized service provider, or (iii) your own installation of end-user replaceable Candura or Candura-approved parts.

Limitation of liability

IF YOUR CANDURA PRODUCT FAILS TO WORK AS WARRANTED ABOVE, YOUR SOLE AND EXCLUSIVE REMEDY SHALL BE REPAIR OR REPLACEMENT. CANDURA'S MAXIMUM LIABILITY UNDER THIS LIMITED WARRANTY OR RELATED IN ANY WAY TO THE CANDURA PRODUCT IS EXPRESSLY LIMITED TO THE LESSER OF THE PRICE YOU HAVE PAID FOR THE PRODUCT OR THE COST OF REPAIR OR REPLACEMENT OF ANY HARDWARE COMPONENTS THAT MALFUNCTION IN CONDITIONS OF NORMAL USE.

CANDURA SHALL NOT BE LIABLE FOR ANY DAMAGES CAUSED BY THE PRODUCT OR THE FAILURE OF THE PRODUCT TO PERFORM, INCLUDING ANY LOST PROFITS OR SAVINGS OR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. CANDURA SHALL NOT BE LIABLE FOR ANY CLAIM MADE BY A THIRD PARTY OR MADE BY YOU FOR A THIRD PARTY.

THIS LIMITATION OF LIABILITY APPLIES WHETHER DAMAGES ARE SOUGHT, OR A CLAIM MADE, UNDER THIS LIMITED WARRANTY OR AS A TORT CLAIM (INCLUDING NEGLIGENCE AND STRICT PRODUCT LIABILITY), A CONTRACT CLAIM OR ANY OTHER CLAIM. THIS LIMITATION OF LIABILITY CANNOT BE WAIVED OR AMENDED BY ANY PERSON. THIS LIMITATION OF LIABILITY WILL BE EFFECTIVE EVEN IF CANDURA KNEW OR SHOULD HAVE KNOWN OF THE POSSIBILITY OF ANY SUCH DAMAGES. THIS LIMITATION OF LIABILITY, HOWEVER, WILL NOT APPLY TO CLAIMS FOR PERSONAL INJURY. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS THAT MAY VARY FROM STATE TO STATE OR FROM COUNTRY TO COUNTRY. YOU ARE ADVISED TO CONSULT APPLICABLE STATE OR COUNTRY LAWS FOR A FULL DETERMINATION OF YOUR RIGHTS.

Software technical support

Software technical support is defined as assistance with questions and issues about the software that was either preinstalled by Candura on the Candura Product or that was included with the Candura branded product at the time of your purchase or lease of the product. Technical support for software is available for the duration of your warranty period. Your dated sales or delivery receipt, showing the date of purchase or lease of the product, is your proof of the purchase or lease date. You may be required to provide proof of purchase or lease as condition of receiving software technical support. After the first ninety (90) days, technical support for software that was either preinstalled by Candura on the Candura Product or include with the Candura Product at the time of your purchase or lease of the product is available for a fee.

Warranty transfer to another country

Candura is not responsible for any handling fees, tariffs, or import duties that may be incurred in transferring the Products. Products and software may be covered by export controls issued by Canada or other governments.

Table of contents

Introduction.....	1
Safety.....	2
Quick Start.....	3
Hookup Configurations.....	5
Hookup Diagnostic Warnings.....	7
Power Flow+ Firmware Features.....	10
RMS Data Storage.....	10
Harmonics and Waveform Storage.....	10
Power Calculations.....	10
Total Harmonic Distortion (THD).....	10
Frequency.....	10
Event Capture.....	11
Current Inrush.....	11
Voltage and Current Unbalance.....	11
Back Panel.....	12
Front Panel.....	13
Logger Operation.....	14
Turning On and Off.....	14
Memory Card.....	14
Setup.....	16
Logging Setup.....	16
RMS Storage Interval.....	16
Connection Type (1P2W, 1P3W, 3P3W, 3P4W and 2.5E).....	17
Trigger Levels.....	17
Line Voltage.....	17
Line Frequency.....	18
Over Voltage.....	18
Under Voltage.....	18
Over Frequency.....	19
Under Frequency.....	19
Spike Detect.....	19
Current Inrush.....	19
Scale Factor.....	20
Voltage Range.....	20
Ext PT.....	20
Clamp (or Flex) CT.....	20
Ext CT.....	20
Channel 4 CT.....	20
System Setup.....	21
Setup Lock.....	21
Logger ID.....	21
Time and Date Setting.....	21
Calibration.....	21
Current Calibration.....	22
Voltage Calibration.....	22
Channel 4 Voltage and Current.....	22
Frequency.....	22


Table of contents

Power Calibration.....	22
Load Setup.....	23
Display.....	23
Measured Data.....	23
Voltage, Current and Frequency.....	23
Channel 4I Voltage and Current.....	23
Real Power and Apparent Power.....	23
Reactive Power and Power Factor.....	24
Total Power.....	24
CH4 Power.....	24
Data Statistics.....	24
Voltage Statistics.....	24
Instantaneous Voltage Statistics.....	24
Average Voltage Statistics.....	25
Voltage THD Statistics.....	25
Current Statistics.....	25
Instantaneous Current Statistics.....	25
Average Current Statistics.....	25
Current THD Statistics.....	26
Power statistics.....	26
Real Power Statistics.....	26
Apparent Power Statistics.....	26
Power Factor Statistics.....	26
Channel 4 Voltage and Current Statistics.....	27
Channel 4 Voltage.....	27
Channel 4 Current.....	27
Waveform Display.....	27
Harmonic Bar Chart Display.....	27
Memory Statistics.....	27
Logger Statistics.....	27
Record.....	28
Start Recording.....	28
Stop Recording.....	28
Sleep or Low Power Mode.....	28
RS-232 Interface.....	28
RS-232 Cable Configuration.....	28
Specifications.....	29
Measurement.....	29
Recording.....	29
Power Supply and Battery Charger.....	29
Environmental.....	30
Safety.....	30
Notes.....	31

Introduction

The **PowerPro** represents leading edge technology in the measurement of Power Quality. From the logger front panel or, for more detail, using Candura Instrument's **PowerView** software you can view:

- Trends in Voltage, Current, Power and Frequency
- Waveforms and harmonic activity for both voltage and current
- Voltage sags and swells
- Voltage transients
- Current Inrush
- Frequency deviations
- Flicker (IEC 868 / IEC 61000-4-15) - *Optional*



The **PowerPro** is an 8 channel power quality analyzer / data recorder. It monitors 3 phases of voltage and current as well as a neutral voltage and current. Measured parameters are updated every cycle to ensure that nothing is missed. Most measurements can be viewed on the front panel LCD in the field and recorded data can be transferred to a computer using the removable memory card. A serial interface provides the means to program the unit and to upgrade the **PowerPro** firmware. The logger is powered from the V1 voltage measurement input, or if V1 is a weak source an auxiliary power supply may be used. The **PowerPro** has an internal battery that can power the unit for up to 5 hours in the event of a power outage. Voltage inputs are protected with metal oxide varistors and fuses for safety. The entire unit is enclosed in a rugged weather proof case for use in harsh environments.

Safety

Although this instrument is designed to be as safe as possible, safety is ultimately the responsibility of the operator. This instrument should only be operated as specified by the manufacturer and by authorized personnel.

Please read and UNDERSTAND the following information before operating this instrument

- The **PowerPro** uses a membrane keypad that could be damaged if a sharp object is brought into contact with it. This may expose the operator to potentially hazardous voltages.
- Frequently inspect the test leads and the instrument for damage. If the instrument shows any signs of physical damage or functions improperly, it should not be used. Clean with a damp cloth only.
- Never work alone with high voltage circuits. Ensure that a qualified observer is mindful of your activities.
- When performing any measurements involving high voltage circuits, all connections should be made to the circuits while the power is off. To ensure personal safety, the test leads and related connectors should not be handled while the circuit is energized.
- Do not attempt to measure any voltage higher than the maximum rating of 600V RMS. Failure to observe the maximum rating could result in damage to the equipment or personal injury.
- Refer servicing of this instrument to qualified personnel only. Disconnect supply power before servicing. Potentially lethal voltages may be present inside the case. If any of the protective circuitry is improperly repaired, the safety of this product could be compromised.
- Do not expose the **PowerPro** *directly* to outdoor elements.
- The following international symbol is used on the equipment and in this manual:




See explanation in manual to find out the nature of the potential HAZARD and any actions to be taken.

Quick Start

Connecting the **PowerPro** to the circuit to be measured is a straightforward process.

1. Connect the voltage leads for each phase to be measured. For proper operation V1 must always be used. Three phase circuits can be connected in either a 'wye' or 'delta' configuration. Refer to the 'Hookup Configurations' section for the various methods of connecting the voltage leads.
2. Connect the phase CT clamps or the three phase Flex CT.

Note that only one or the other may be used - if the three phase Flex CT is used then the phase CT clamps must be disconnected. The neutral CT clamp may be used at the same time as the three phase Flex CT.



3. Ensure a memory card is installed.
4. Turn the unit on (if it is turned off) by pressing and holding any key except F6.
5. Use the 'SETUP' key and function keys to check and modify any of the setup parameters.
6. Press the 'Record' key and then F2 to start recording. If there are any error messages, please refer to the 'Hookup Diagnostic Warnings' section.
7. The measured values can be viewed from the unit using 'DISPLAY' key and function keys.

Continued....

Quick Start continued


- To stop recording press the 'RECORD' key and then F4 followed by F1 to confirm the stop command.

Note: Static discharges may occur when connecting leads, communication cable or memory card, depending on environmental conditions. This is not hazardous and will not damage the unit. However it may affect the integrity of the data if the unit is recording. Connection and disconnection of leads etc. should be done while the unit is not recording. Before handling a unit that is recording the operator should discharge any potential static by touching a grounded object.


- Data is transferred to a computer using the memory card. When recording has been stopped the memory card can be removed from the unit. The memory card can be inserted directly into a card reader or, with a PCMCIA adapter, it can be inserted into a PCMCIA slot in a laptop computer. Run **PowerView** and select 'File', 'Open' and then go to the drive that has been configured for the memory card. If there is data on the card you will then see a file that can be opened. After opening the file, a directory and file name (you can keep the same file name) must be selected for the processed file.

Hookup Configurations


The **PowerPro** can be used to monitor any three phase power configuration. Following are descriptions of the five most common field setups:



1 Phase 2 Wire (1P2W)



1 Phase 3 Wire (1P3W)




3 Phase 3 Wire (3P3W)
(Blondel or 2 Wattmeters Method)


* Optional: CT2 and V3 are not used in Total Power Calculation

Continued....

Hookup Configuration continued



3 Phase 4 Wire (3P4W)



2 1/2 Element (2.5E)



Note: If a 3 phase Flex CT is connected then CT1, CT2, and CT3 must be disconnected.

Hookup Diagnostic Warnings

Before the unit starts recording it does a number of checks on the connected signals, if it detects a potential problem a message is displayed and the operator must select either 'Retry' or 'Ignore' – if the operator presses 'ESC', 'SETUP', 'DISPLAY' or 'RECORD' the start process is aborted.

Possible messages and descriptions:

- 'Voltage 1 Too Low'**
- 'Voltage 2 Too Low'**
- 'Voltage 3 Too Low'**

-Voltage being measured is less than 35V on 240V range or less than 90V on 600V range.

- 'Voltage 1 Too High'**
- 'Voltage 2 Too High'**
- 'Voltage 3 Too High'**

-Voltage being measured is greater than 300V on 240V range or greater than 750V on 600V range.

- 'Current 1 Too High'**
- 'Current 2 Too High'**
- 'Current 3 Too High'**

-Current being measured is greater than 125% of the CT rating.

- 'Voltage Hookup Error'**

-This indicates that the operator has selected a single phase configuration but has connected to a three phase system or vice versa.

- 'V2 Inverted'**

-Voltage leads on channel two are reversed.

Continued....

Hookup Diagnostic Warnings continued**'V3 Inverted'**

-Voltage leads on channel three are reversed.

'-ve Power Check CT#1'**'-ve Power Check CT#2'****'-ve Power Check CT#3'**

-This usually means that the relevant CT has been connected in reverse. To fix the problem remove the CT, rotate it 180 degrees, reconnect it and then press 'Retry'. In some cases this is not an error (i.e. when measuring a generator output) and pressing 'Ignore' is the correct response.

'Phase Sequence Error'

-This occurs for three phase installations and indicates that the measured phase sequence is not ABC. To fix the problem swap the B and C voltage leads and then press 'Retry'.

'Data Sync Error'

-This problem is internal to the unit. To fix the problem put the unit to sleep (press 'RECORD' and then 'F6') and then wake it up (press and hold any key except 'F6'). If this does not fix the problem please contact your nearest Product Support Centre.

'Freq Event Triggered'

-This indicates that an under/over frequency condition is active. This may indicate that the trigger levels are not set up properly (to view them press 'SETUP' and 'F2').

Hookup Diagnostic Warnings**'Volt Event Triggered'**

-This indicates that an under/over voltage condition is active. This may indicate that the trigger levels are not set up properly (to view them press 'SETUP' and 'F2').

Power Flow Firmware+ Features

RMS Data Storage

The **PowerPro** stores RMS data at set intervals which can be adjusted from 1 to 30 seconds or 1 to 30 minutes. The minimum, maximum and average values are stored at the end of each storage interval. The averaged values are calculated from the sum of the RMS values (updated every cycle) over the preceding storage interval. The minimum and maximum values are updated every cycle over the preceding storage interval.

Harmonics and Waveform Storage

The unit displays up to the 21st harmonic on its display while the software displays up to the 64th harmonic.

Power Calculations

The power calculations are updated every cycle. Only the averaged values of power are recorded. Power factor displayed is the true power factor (not the displacement power factor which is determined from the phase angle shift between voltage and current) and is calculated as the ratio of the real power (KW) divided by the apparent power (KVA).

Total Harmonic Distortion (THD)

THD is calculated as the ratio between the square root of the squared sum of the harmonic magnitudes (for harmonics 2...64) divided by the fundamental value.

Frequency

The system frequency is measured from the signal on V1 input. Frequency will not be measured if the voltage is below 25V.

Power Flow Firmware+ Features

Event Capture

Under/over voltage events, high speed voltage transients and under/over frequency events are stored when they occur. The trigger levels are set from the Setup menu under 'TRIGGER LEVELS'. The duration of the events are recorded with one cycle resolution.

Voltage events are tagged as sags/swells if they are under 2 seconds in duration and under/over if they are longer. The **Power View** software reports their duration in number of cycles for events less than 10 seconds and in seconds for longer events. The logger uses a hysteresis value of 0.1% of full scale to determine when the event has finished. For example if the under-voltage trigger level is set at 228.0 volts the logger will start recording an event when the voltage goes under 228.0 volts and will stop recording the event when the voltage goes over 228.3 volts.

The **PowerPro** can capture high speed voltage transients that are 65 microseconds or longer. When a transient is detected on any of the three voltages, five cycles (2 pre-trigger and 3 post-trigger) of waveforms are stored. All voltage and current waveforms are stored independent of which voltage channel the event was on.

Current Inrush

Current inrush data is stored when the current on any channel, except neutral, exceeds the threshold setting. Both 20 seconds of RMS data, with one cycle resolution, and 5 cycles of waveform data are stored for each current inrush.

Voltage and Current Unbalance


Unbalance is calculated as the ratio of the negative sequence component divided by the positive sequence component.

Back Panel

The voltage and current connections are colour coded according to phase and polarity (for voltage).

Phase 1 or Phase A	Red
Phase 2 or Phase B	Yellow
Phase 3 or Phase C	Blue
Neutral Current	Grey
Neutral Voltage	White

There is a dedicated connector for a three phase Flex CT. This connector supplies the power to the Flex CT and receives the 3 isolated current signals. There is an auxiliary connector that is used to connect to an external DC power supply (for use when V1 is connected to a weak source).




When measuring less than 3 voltages V1 must always be used. V1 zero crossing is used to synchronize the data sampling and measure frequency. In the event of an outage on V1 the logger has an internal digital phase lock loop that simulates the zero crossing until V1 is restored.

Either phase CT's or a three phase Flex CT may be used to monitor phase current. Only one type of CT may be connected to the logger at a time - if the three phase Flex CT is used then the phase CT's MUST be disconnected from the logger. Leaving the phase CT's connected will cause errors in the Flex CT readings.

Front Panel

The front panel of the **PowerPro** has a graphics display, a 10 button keypad, an RS-232 communications port and a memory card interface.



The graphics display is 240x64 pixels with an LED backlight. Text on the display is organized in 8 lines by 40 characters (small characters) or in 4 lines by 20 characters (large characters), some screens incorporate both types of characters. Graphics (waveforms and harmonic bar chart) are also displayed with text.

The keypad has two types of buttons. The bottom row of 4 keys are fixed function buttons and the top row of 6 keys are function keys that change function depending on the active screen on the display. In most screens the bottom line of the display is in inverse video and is used to describe the functions associated with the six function keys.

The RS-232 communications port is a 3 wire (Rx, Tx, Gnd) serial interface. The RS-232 serial interface is used to synchronize the **PowerPro** real time clock with a computer clock. It is also used to upgrade firmware when connected to a computer and running **PowerView** software.

The memory card interface is used to store recorded data on a memory card. The **PowerPro** will not begin a survey without a memory card installed. Once a survey has been started the memory card may not be removed until the survey has been stopped.

Logger Operation

Turning On and Off

The **PowerPro** should be put into low power (or sleep) mode when not in use. In low power mode only the real time clock and keypad interface are active. Current consumption from the battery is reduced to less than 100 microamps. The logger is put in low power mode by pressing the 'RECORD' button followed by the F6 (SLEEP) button. The logger will put itself into low power mode when it detects a low internal battery voltage. If the logger was recording at the time it will close the data files as if the operator had stopped recording before going into low power mode. After going into low power mode due to a low battery voltage the battery will have enough capacity to keep the real time clock functioning for over a month.

To turn the logger on any key (except F6) must be pressed and held for approximately 1 second. When the logger powers up it does a self diagnostic on internal functions, if an error is detected a diagnostic screen is displayed and the logger waits for an operator to elect to put the logger back into sleep mode or to re-initialize the logger (reboot).

Memory Card

The logger continually checks the memory card interface to see if a card has been inserted or removed. When it detects a card being inserted (or a card in the socket immediately after power up) the logger checks the card size. The operator must press any key to continue. The logger can now be used to start a survey and data will be stored on the memory card.

When the logger detects a card being removed it changes the screen to the initial screen if the logger was not recording. If the logger was recording when the memory card is removed it displays an error message:

'MEM Card Error. Please Re-Insert
MEM Card or Survey will end in xx seconds'

The number of seconds depends on the time until the next storage time. Even if the card is re-inserted in time it is possible that data on the card may be corrupted.

Logger Operation (Memory Card)

The Memory card should NEVER be removed while data are being recorded, ALWAYS stop recording before removing the Memory card.

The Memory card offers a fast and convenient method to transfer recorded data to a computer. To transfer data from the memory card to a computer, remove the card from the unit and insert into the PCMCIA slot of the computer using a PCMCIA adapter or insert directly into a card reader. Select 'File' from the **PowerView** toolbar and then select 'Open'. Change the directory to the drive that has been configured for the memory card. If there is data on the card you will see a file that can be opened. After opening the file, a directory and the file name (you can keep the same file name) must be selected for the processed file.

Logger Operation

Setup

Pressing the 'SETUP' button calls up the main setup screen. From the main setup screen you can select 'LOGGING SETUP', 'TRIGGER LEVELS', 'FLICKER SETUP', 'SCALE FACTOR' or 'SYSTEM SETUP'.

Logging Setup

Pressing F1 to select 'LOGGING SETUP' allows the operator to select and change the RMS storage interval, the harmonic storage interval and the wiring configuration. The operator must press 'NEXT VALUE' until the desired setup parameter is highlighted and then press 'CHANGE VALUE' to be able to modify the selected setup parameter. To exit press 'ESC' and the display will return to the parameter list screen.

If the logger is recording and 'CHANGE VALUE' is selected the screen will change to the modification screen, 'Recording On' will be printed on the bottom and no changes will be allowed.

If the Lock function is on and 'CHANGE VALUE' is selected the screen will change to the modification screen, 'LOCK On' will be printed on the bottom and no changes will be allowed.

RMS Storage Interval

The RMS storage interval appears on the left side of the screen and can be adjusted to between 1 and 30 seconds or 1 and 30 minutes.

Logger Operation (Setup - Logging setup)

Connection Type (1P2W, 1P3W, 3P3W, 3P4W and 2.5E)

This allows the unit to be configured for the five most common configuration types:

1P2W	1 Phase 2 Wire
1P3W	1 Phase 3 Wire (Edison circuit)
3P3W	3 Phase 3 Wire (Delta circuit)
3P4W	3 Phase 4 Wire (Wye circuit)
2.5E	2½ Element

Recording of channel 4 voltage and current can be enabled or disabled for any of these five configuration types.

Trigger Levels

The trigger levels for under/over voltage and under/over frequency are set here. An event is triggered when either one of the phase voltages or frequency is equal to its trigger level. The event is finished when the value goes back 0.75V (hysteresis) more/less than its trigger level. The hysteresis value is based on the full scale range.

Line Voltage

This allows the operator to set the nominal line voltage. The under/over voltage levels are automatically adjusted as a percent of this value. For example, if the nominal system voltage is 240V with an under voltage setting of 216.0V (90%) and the operator adjusts the nominal system voltage to 120V then the under voltage setting will automatically change to 108.0V (90%).

For convenience there are four 'speed' buttons that can be used to set the nominal line voltage directly to 120V, 220V, 480V, 600V.

Logger Operation (Setup - Trigger Levels)

Line Frequency

This allows the operator to set the nominal line frequency (50 or 60 hertz). The under/over frequency levels are automatically adjusted as a fixed offset from this value. For example, if the nominal line frequency is 60 Hz with an over frequency setting of 60.50 Hz and the operator adjusts the nominal system frequency to 50 Hz then the over frequency setting will automatically change to 50.50 Hz

Over Voltage

When the trigger level screen is selected and the over voltage setting is not highlighted then the trigger level for V1 is displayed. When the over voltage setting is highlighted then all three voltage trigger levels are displayed. Pressing 'CHANGE VALUE' displays the screen that allows modification of these values.

The trigger levels can be changed individually ('SELECT NEXT' allows selecting which phase to change) or they can be changed at the same time ('SELECT ALL' selects all three phases). If they are all selected pressing 'SELECT NEXT' puts the display back into individual change mode.

The trigger levels can be changed in increments of 0.1% and for convenience there are two 'speed' buttons that set the levels directly to +4.2% and +5.8%.

Under Voltage

When the trigger level screen is selected and the under voltage setting is not highlighted then the trigger level for V1 is displayed. When the under voltage setting is highlighted then all three voltage trigger levels are displayed. Pressing 'CHANGE VALUE' displays the screen that allows modification of these values.

The trigger levels can be changed individually ('SELECT NEXT' allows selecting which phase to change) or they can be changed at the same time ('SELECT ALL' selects all three phases). If they are all selected pressing 'SELECT NEXT' puts the display back into individual change mode.

Logger Operation (Setup - Trigger Levels)

The trigger levels can be changed in increments of 0.1% and for convenience there are two 'speed' buttons that can be used to set the values directly to -8.3% and -11.7%.

Over Frequency

The over frequency setting is set with a resolution of 0.01 Hz. The minimum and maximum settings are ± 4.00 Hz with an override that the over frequency setting must be 0.10 Hz greater than the under frequency setting. For convenience there are four 'speed' buttons that can be used to set the values directly to +0.10 Hz, +0.25Hz, +0.50 Hz and +1.00 Hz.

Under Frequency

The under frequency setting is set with a resolution of 0.01 Hz. The minimum and maximum settings are ± 4.00 Hz with an override that the under frequency setting must be 0.10 Hz less than the over frequency setting. For convenience there are four 'speed' buttons that can be used to set the values directly to -0.10 Hz, -0.25Hz, -0.50 Hz and -1.00 Hz.

Spike Detect

The voltage waveforms are sampled at a rate of 256 samples / cycle. Sample #n of the present cycle is compared with sample #n of the previous cycle. If the difference is greater than the set level then it is classified as a spike and a waveform is captured – 2 cycles pre-trigger and 3 cycles post-trigger.

Current Inrush

When the current becomes greater than the set level, current and voltage data are captured and stored. 20 seconds of cycle by cycle RMS data and 5 cycles of voltage and current waveforms from the start of the inrush are stored.

Logger Operation (Setup - Scale Factor)**Scale Factor****Voltage Range**

The voltage range is fixed at 600V. The unit can measure up to 750V before the signal is clipped.

Ext PT

To measure voltages greater than 750V external PT's must be used. The ratio of the external PT is entered here so that the **PowerPro** can display primary side values. The maximum ratio that can be entered is 200:1. If this is not sufficient the **PowerView** software can change this ratio after the data is transferred to the computer.

Clamp (or Flex) CT

When 'Change Value' is selected the operator will be able to select 'Clamp CT' in 'Flex CT'. Once the CT type has been selected the operator can select the CT rating. The Clamp CT ratings are 10A, 100A, 200A, 300A, 1000A, and 3000A and the Flex CT ratings are 20A, 200A, 2000A, 300A, 1000A, and 3000A. The **PowerPro** can be calibrated for each of these CT rating and when the operator changes CT ranges the proper calibration factors are automatically set.

Ext CT

In situations where the **PowerPro** is measuring the secondary current of a CT, the ratio of the external CT is entered here so that the **PowerPro** can display primary current values. The maximum ratio that can be entered is 200:1. If this is not sufficient the **PowerView** software can change this ratio after data is transferred to the computer.

Channel 4 CT

There is only a clamp CT interface provided for the channel 4 current measurement. The allowable neutral clamp CT ranges are: 10A, 100A, 200A, 300A, and 1000A.

Logger Operation (Setup)**System Setup**

Under 'SYSTEM SETUP' the operator can modify system related parameters such as locking the setup parameters, changing the logger ID, setting the time and date and calibrating the logger.

Setup Lock

The operator must enter the lock code to enable or disable the setup lock. This code is the same for all **PowerPro** loggers and is not user changeable. The code is '4123'. Turning the lock on inhibits any changes to the setup parameters.

Logger ID

The operator can set these four ID characters to any combination of numbers and upper case letters for convenient tracking of multiple **PowerPro**'s. The factory set 10 digit serial number can also be used for the same purpose.

Pressing 'RECORD' will display the logger ID.

Time and Date Setting

The operator can adjust the time and date setting of the logger. Once changes have been completed the 'SAVE' button must be pressed to save the new settings. The time and date can also be set from the **PowerView** software.

Calibration

Voltage, current, power and frequency readings can be calibrated. Before accessing this menu a 6 digit calibration lock password must be entered. Once this password is entered it will stay in effect until the logger is turned off (ie. Put into sleep mode). The password is not given in this manual, it is provided to the purchaser when the logger is purchased. If the password is lost please email info@candura.com requesting the password and include the logger serial number.

Logger Operation (Setup - System Setup - Calibration)Current Calibration

Each range of Clamp CT's and Flex CT's are independently calibrated. The first step is to select the CT. This is done from the 'SCALE FACTOR' submenu of 'SETUP'. Next select the calibration menu and then select 'CURRENT'. Apply a known and stable current to the CT being calibrated and, using the 'INC' and 'DEC' keys, adjust the reading until it is correct. See also the Power Calibration section.

Voltage Calibration

Select the calibration menu and then select 'VOLTAGE'. Apply a known and stable voltage to the voltage channel being calibrated and, using the 'INC' and 'DEC' keys, adjust the reading until it is correct.

Channel 4 Voltage and Current

The channel 4 voltage and current are calibrated from the same screen. Apply a known and stable voltage that is free of harmonics (the fundamental of the neutral voltage is used for calibration) and, using the 'INC' and 'DEC' keys, adjust the reading until it is correct. Apply a known and stable current that is free of harmonics to the channel 4 CT and, using the 'INC' and 'DEC' keys, adjust the reading until it is correct.

Frequency

Apply a voltage to V1 that has a known and stable frequency and has a magnitude of at least 120V. The frequency should be between 48.000 Hz and 62.000 Hz. Using the 'INC' and 'DEC' keys, adjust the reading until it is correct.

Power Calibration



The power calibration compensates for phase shift errors in the CT. This calibration should be done at the same time as the current calibration. To perform this calibration a stable voltage/current supply capable of supply current with about a 0.7 power factor (either lead or lag) is required. Apply rated voltage and apply rated current to the CT. Next select the 'POWER FACTOR' calibration option. Adjust the power factor of the current to 0.7 and, using the 'INC' and 'DEC' keys, adjust the reading until it is correct.

Calibrating the power factor will also calibrate the real and reactive powers.

Logger Operation (Setup - System Setup)Load Setup

Under 'LOAD SETUP' the operator can save three different setup configuration or load one of the saved configurations. To change one of the preset configurations the operator would access the various set up screens and make the desired changes. Then go to the 'LOAD SETUP' screen and select either 'F4', 'F5', or 'F6' to save the setup configurations.

Display

Pressing the 'DISPLAY' button calls up the main display screen. From this screen you can select measured data ('MEAS DATA'), data statistics ('DATA STATS'), waveforms (), harmonic bar chart (), memory statistics ('MEMORY STATS') and logger statistics ('LOGGER STATS').

Measured Data

This selection brings up a submenu that enables selection of voltage, current and frequency ('VOLTS AMPS'), neutral voltage and current ('CH4 V/A'), real power and apparent power ('WATTS KVA'), reactive power and power factor ('KVAR PF'), and total power ('TOTAL POWER').

Voltage, Current, Frequency and Unbalance

Voltage and current of the three phases are displayed. Also displays frequency of channel 1 voltage, and unbalance of the three phase voltage and current.

Channel 4 Voltage and Current

The DC and AC values for voltage and current are displayed.

Real Power and Apparent Power

Three phases of real power (kW) and apparent power (kVA) are displayed. If the unit is configured for 3P3W (Delta) then individual phase powers are not available, only total power can be viewed.

Logger Operation (Display - Measured Data)Reactive Power and Power Factor

Three phases of reactive power (kVAR) and power factor, leading (LD) or lagging (LG), are displayed. If the logger is configured for 3P3W (Delta) then individual phase powers are not available, only total power can be viewed.

Total Power

Total real, apparent and reactive power and total power factor are displayed.

CH4 Power

Channel 4 power is displayed. This value includes both AC and DC power.

Data Statistics

This selection brings up a submenu that enables selection of voltage statistics ('VOLTS MN/MX'), current statistics ('AMPS MN/MX'), power statistics ('POWER MN/MX'), Channel 4 voltage and current statistics ('CH4 MAX'), flicker statistics ('FLICKER MN/MX'), and frequency statistics ('FREQ MN/MX').

These statistics are compiled for the total survey, each value has a time stamp showing when it occurred. The time stamp has a resolution of 1 second and can be at any time and is not restricted to the data storage time.

Voltage Statistics

Pressing 'F1' from the Data Statistics submenu brings up another submenu that enables selection of instantaneous voltage statistics ('INST MN/MX'), average voltage statistics ('AVERAG MN/MX') and voltage THD statistics ('THD MN/MX').

Instantaneous Voltage Statistics

This is automatically displayed when voltage statistics are first selected. The instantaneous minimum and maximum values (updated every cycle) are displayed along with a time stamp. Channel 1 voltage is displayed first, if more than one channel is being measured then the other channels can be viewed by pressing 'F6' ('NEXT CHAN').

Logger Operation (Display - Data Statistics - Voltage Statistics)Average Voltage Statistics

Pressing 'F2' selects the average voltage statistics. The average minimum and maximum values (updated every storage interval) are displayed along with a time stamp. Channel 1 voltage is displayed first, if more than one channel is being measured then the other channels can be viewed by pressing 'F6' ('NEXT CHAN').

Voltage THD Statistics

Pressing 'F3' selects the voltage THD statistics. These are instantaneous values. The voltage THD minimum and maximum values (updated every 30 cycle) are displayed along with a time stamp. Channel 1 voltage THD is displayed first, if more than one channel is being measured then the other channels can be viewed by pressing 'F6' ('NEXT CHAN').

Current Statistics

Pressing the 'F2' from the Data Statistics submenu brings up another submenu that enables selection of instantaneous current statistics ('INST MN/MX'), average current statistics ('AVERAG MN/MX') and current THD statistics ('THD MN/MX').

Instantaneous Current Statistics

This is automatically displayed when current statistics are first selected. The instantaneous minimum and maximum values (updated every cycle) are displayed along with a time stamp. Channel 1 current is displayed first, if more than one channel is being measured then the other channels can be viewed by pressing 'F6' ('NEXT CHAN').

Average Current Statistics

Pressing 'F2' selects the average current statistics. The average minimum and maximum values (updated every storage interval) are displayed along with a time stamp. Channel 1 current is displayed first, if more than one channel is being measured then the other channels can be viewed by pressing 'F6' ('NEXT CHAN').

Logger Operation (Display - Data Statistics - Current Statistics)Current THD Statistics

Pressing 'F3' selects the current THD statistics. These are instantaneous values. The current THD minimum and maximum values (updated every 30 cycle) are displayed along with a time stamp. Channel 1 current THD is displayed first, if more than one channel is being measured then the other channels can be viewed by pressing 'F6' ('NEXT CHAN').

Power Statistics

Pressing 'F3' from the Data Statistics submenu brings up another submenu that enables selection of real power statistics ('WATTS MN/MX'), apparent power statistics ('VA MN/MX'), reactive power statistics ('VARS MN/MX') and power factor statistics ('PF MN/MX').

Real Power Statistics

This is automatically displayed when power statistics are first selected. The average real power minimum and maximum values (updated every storage interval) are displayed along with a time stamp. Channel 1 real power is displayed first, if more than one channel is being measured then the other channels can be viewed by pressing 'F6' ('NEXT CHAN').

Apparent Power Statistics

Pressing 'F2' selects the apparent power statistics. The average apparent power minimum and maximum values (updated every storage interval) are displayed along with a time stamp. Channel 1 apparent power is displayed first, if more than one channel is being measured then the other channels can be viewed by pressing 'F6' ('NEXT CHAN').

Power Factor Statistics

Pressing 'F4' selects the power factor statistics. The average power factor minimum and maximum values (updated every storage interval) are displayed along with a time stamp. Channel 1 power factor is displayed first, if more than one channel is being measured then the other channels can be viewed by pressing 'F6' ('NEXT CHAN').

Logger Operation (Display - Data Statistics - Power Statistics)Channel 4 Voltage and Current Statistics

Pressing 'F4' the Data Statistics submenu brings up another submenu that enables selection of CH4 voltage ('CH4 VOLTS') and CH4 current ('CH4 AMPS').

Channel 4 Voltage

This is automatically selected when channel 4 statistics are first selected.

Channel 4 Current

Pressing 'F2' selects the channel 4 current statistics.

Waveform Display

Pressing 'F3' from the Display menu displays one cycle of voltage and current waveform. On the left of the waveform, voltage and power information is displayed and on the right of the waveform, current and power information is displayed. This display is updated once a second. The 'F1' key is used to freeze ('HOLD') and release ('GO') the display. The 'F6' key is used to select different channels for display.

Harmonic Bar Chart Display

Pressing 'F4' from the Display menu displays the first 21 harmonics (including even harmonics) of phase voltage and current. This display is updated once a second. The 'F1' key is used to freeze ('HOLD') and release ('GO') the display. The 'F6' key is used to select different channels for display.

Memory Statistics

Pressing 'F5' from the Display menu displays memory usage. The number of records available and used for both RMS/power data and event data are displayed.

Logger Statistics

Pressing 'F6' from the Display menu displays the logger serial number, the firmware revision level and the internal battery capacity.

Logger Operation

Record

Pressing the 'RECORD' button calls up the recording screen. From this screen you can start recording, stop recording and turn the unit off (SLEEP).

Start Recording

Pressing 'F2' will initiate recording start. If there is data in the unit from a previous survey the operator must first reset the memory. The logger then does a diagnostic check on the voltage and current connections - see section 'Hookup Diagnostic Warnings'. Once the diagnostics have been completed and passed (or the operator has ignored the diagnostic warnings) recording will start.

Stop Recording

Pressing 'F4' will initiate recording stop. If the unit is recording data the operator will be required to confirm that recording is to stop. If the unit is not recording data pressing 'F4' will cause no action.

Sleep or Low Power Mode

Pressing 'F6' will put the unit into sleep or low power mode. If the unit is recording data the operator will be instructed to stop recording before putting the logger to sleep. In sleep mode only the internal real time clock and the keypad interface are running. Pressing and holding any key, except 'F6', for about one second will return the logger to active mode.

RS-232 Interface

RS-232 Cable Configuration

The **PowerPro** uses a standard DB9 male to DB9 female 'straight-through' cable. Although there are nine conductors only three of them are used.

DB9 Male (logger)	DB9 Female (computer)
Pin 2	Pin 2
Pin 3	Pin 3
Pin 5	Pin 5

The RS-232 serial interface is used to synchronize the **PowerPro** real time clock with a computer clock. It is also used to upgrade firmware when connected to a computer and running **PowerView** software.

Specifications

Measurement

	Specifications	Comment
V1, V2, V3 0 - 600 VAC	0.2 % of full scale	-
V4 0 - 80VAC/DC	0.2% of full scale	-
I1, I2, I3 0 - 1V (Clamp) 0 - 2.5V (Flex)	0.2% of full scale	CT's are voltage output
I4 0 - 1VAC/DC	0.2% of full scale	CT's are voltage output
Sampling	256 sample/cycle every cycle	31 - 65Hz
	32 sample/cycle every cycle	31 - 450Hz

Recording

	Specifications	Comment
Storage Rate	1, 5, 10, 15, 30 sec or 1, 5, 10, 15, 10 min	-
Memory	1G removable memory card	Maximum recording duration 18 hours up to 999 days

Power Supply and Battery Charger

	Specifications	Comment
Internal Power Supply	20VA 90 - 600VAC	Operated from voltage on V1 measuring channel.
External Power Supply	Input: 120VAC \pm 10%, 60Hz, 16W. Output: 12VDC, 800mA, Class2	Mode Electronics Model KA12D120080046U, p/n 68-128P-1
Battery Run Time	5 hours	-

Specifications

Environmental

	Specifications	Comment
Operating Temperature	-20°C to 60°C	-
Humidity	Max 80% relative non condensing	-
Altitude	Max 2000m	-

Safety

	Specifications	Comment
Approval	CAN/CSA-C22.2 No. 61010-1-04	-
	Pollution Degree 2	Normally only non-conductive pollution occurs. However, temporary conductivity caused by occasional condensation must be expected.
	600V CAT-IV	Measurement category IV is for measurements performed in the building installation.

Notes